



PARTS CATALOG


Model HT490WV

MACHINE BODY

APR. 2003

FUJIROBIN INDUSTRIES LTD.

HT490WV PARTS LIST



HT490WV PARTS LIST

MACHINE BODY

KEY NO.	PART NO.	Q'TY	DESCRIPTION	REMARKS
1	303510100	1	CASE	
2	029060400	1	GREASE NIPPLE	
3	303510700	1	CRANK SHAFT	
4	030081400	1	FLANGE NUT	M8
5	303511100	1	CRANK PLATE	
6	303510800	1	CRANK GEAR	
7	303510400	1	GASKET	
8	303511200	1	GREASE PLATE	
9	303513000	1	GASKET	
10	303510200	1	CASE COVER	
11	032040000	6	SPRING WASHR	M4
12	065041200	6	TORX BOLT	M4X12
13	065051500	1	TORX SCREW	M5X15
14	065052500	2	TORX SCREW	M5X25
15	099861500	1	CLAMP	
21	370355100	1	FLANGE	

HT490WV PARTS LIST

22	035600103	2	BALL BEARING	#6001 LL
23	045002800	1	SNAP RING	R-28
24	303555200	1	CLUTCH DRUM	
25	045001202	1	SNAP RING	S-12
26	303355300	1	GEAR	
27	048041200	2	PIN	
28	065052000	3	TORX SCREW	M5X20
31	303520100	1	GUIDE CUTTER	
32	068053500		BOLT	M5X35
33	030051400	2	NAT FLANGE	M5
34	303522000	2	BLADE CUTTER	
35	303520900	4	BLOCK GUIDE	
36	306020400	4	BLADE BOLT WASHER	
37	065052000	4	TORX SCREW	M5X20
38	303329000	1	PROTECTOR	
39	030051100	4	NUT	M5
40	303560100	1	COVER CUTTER BLADE	
51	303330100	1	FRONT HANDLE	

HT490WV PARTS LIST

52	303331100	1	PLATE FRONTHANDLE	
53	032050000	2	SPRING WASHER	M5
54	030051600	2	NUT,NYLON	

MACHINE BODY

KEY NO.	PART NO.	Q'TY	DESCRIPTION	REMARKS
61	303340110	1	REAR HANDLE (A)	
62	303340210	1	REAR HANDLE (B)	
63	303340310	1	LEVER THROTTLE	
64	303340500	1	SPRING THROTTLE LEVER	
65	303340600	1	LEVER LOCK	
66	303340700	1	SPRING LOCK LEVER	
67	303340800	1	PIN LOCK	
68	303340900	1	SPRING LOCK PIN	
69	099832600	1	STOP SWITCH	
70	303341300	5	TAPPING SCREW	4.5X16
71	099861000	1	WIRE THROTTLE	

HT490WV PARTS LIST


72	303341000	1	REAR HANDLE HOLDER	
73	303341200	1	HOLDER THROTTLE WIRE	
74	303341300	1	TAPPING SCREW	4.5X16
75	303341100	2	BUSH	
76	065061800	2	SCREW	M6X18
80	370540000	1	CLUTCH AY	
81	370540100	1	CLUTCH GUIDE	
82	305077000	1	SHOE CLUTCH SPRING	
84	305040411	1	CLUTCH PLATE	
85	005041200	2	FLAT HEAD SCREW	M4X12
86	005061800	1	FLAT HEAD SCREW	M6X18
91	060000022	1	TOOL BAG	
92	302040600	1	SPANNER	8X10
93	060000015	1	COM,WRENCH /TORX DRIVER	13X19
94	099890100	1	GOGGLE	

HT490WV PARTS LIST

101	303350100	1	ENGINE BASE	
102	002051200	4	SCREW	M5X12
103	0736359980	1	LABEL,CUATION	

ENGINE BODY

HT490WV PARTS LIST



HT490WV PARTS LIST

ENGINE BODY

KEY NO.	PART NO.	Q'TY	DESCRIPTION	REMARKS
*1	5191006000	1	CRANKCASE ASSY	Incl.2,3,6,7
2	0600109980	2	BALL BEARING	#6000
3	0440109980	2	OIL SEAL	φ10 Xφ20 X 5
4	5191500601	1	CYLINDER	
5	5191500301	1	GASKET,CYLINDER	
6	5191500400	1	GASKET,CRANKCASE	
7	0140059520	3	SCREW	M5X25
8	0119059730	2	SOCKET HEAD BOLT	M5X20
11	5192003002	1	CRANKSHAFT COMPL	
12	5192500800-1	1	PISTON	
13	5192500600	1	RING,PISTON	
14	5192500500	1	PIN,PISTON	
15	0565089970	2	CLIP	
20	5193002002	1	MUFFLER,EXHAUST	

HT490WV PARTS LIST

21	5213001000	1	INSULATER COMPL	
22	5193500201	1	COVER,MUFFLER	
23	5193500301	1	INSULATOR,MUFFLER	
24	0119059600	2	SOCKET HEAD BOLT	M5 X 45
25	5233503902	1	GASKET,INSULATER	
26	5193500302	1	GASKET,MUFFIER	
27	0140059400	2	SCREW ASSY	M5X20
28	0140059550	1	SCREW	M5X14
*40	5195003003	1	STARTOR,REWIND	Incl.41~48,57.
41	5225004020	1	STARTER KNOB	
42	5195002050	1	SPIRAL SPRING	
43	5255016020	1	ROPE	
44	5195002030	1	REEL	
45	5195002110	1	COLLAR	
46	5255001040	1	DAMPER	
47	5195002100	1	SWING ARM	
48	5195002060	1	SET SCREW	
49	0043704120	4	SCREW	

HT490WV PARTS LIST

50	5195006301	1	COVER,CYLINDER	
51	0140059490	1	SCREW	M5X14
52	5257500300	1	GROMMET	
53	5503503001	1	SPACER,COVER	
54	5199505600	1	LABEL,MODE	
55	5195500800	1	HOUSING,BLOWER	

ENGINE BODY

KEY NO.	PART NO.	Q'TY	DESCRIPTION	REMARKS
56	0150059980	3	TAPPING SCREW	M5X20
57	5195500000	1	PULLEY	
58	5219500200	1	LABEL,TRADE MARK	
59	0736309910	1	LABEL,SOUND LEVEL	106db
60	5196011000-2	1	TANK,FUEL CP	
61	5236503900	1	FILTER	
62	0851149950	1	TUBE	
63	5196500201	1	PLATE,TANK FUEL	
65	0043605100	1	SCREW ASSEMBLY	M5 X10
66	6151500700	2	TAPPING SCREW	


HT490WV PARTS LIST

67	0561059990	1	HOSE CLAMP	
68	5196500301	1	DAMPER	
69	0031005000	2	WASHER	
*70	5256059000	1	CAP,FUEL TANK AY	Incl.71,72
71	5256058000	1	CAP,FUEL TANK AY	
72	5256067000	1	STRAP AY	
80	5197003014	1	FLYWHEEL	
81	5197003021-1	1	COIL	
82	0655009940	1	CAP,PLUG	
83	0654009931	1	SPRING,PLUG CAP	
84	0650149650	1	PLAG,SPARK	BMR4A
85	0140049920	2	SCREW	M4 X20
88	5257018001-2	1	WIRE CP	
89	5197500002	1	COVER,PLUG CAP	
90	0031008000	2	WASHER	M8
91	0173089990	1	LOCK NUT	M8

HT490WV PARTS LIST

CARBURETOR & AIR CLEANER

HT490WV PARTS LIST



HT490WV PARTS LIST

CARBURETOR & AIR CLEANER

KEY NO.	PART NO.	Q'TY	DESCRIPTION	REMARKS
*1	5196006000	1	CARBRETOR	Incl.2~17 WYL-108
2	5236046130	1	BODY ASSY PUMP	Incl.17
3	5236046060	1	BODY ASSY AIR PURGE	
4	5236046050	1	COVER,PRIMARY PUMP	
5	5246001150	1	PUMP PRIMARY	
6	5316005250	1	DIAPHRAGM ASSY METALING	
7	5236046040	1	GASKET,METALING DIAPHRAGM	
8	5246001040	1	DIAPHRAGM PUMP	
9	5246001030	1	GASKET PUMP	
10	5256024020	1	JET	#39.0
11	5246001010	1	O-RING	
12	5316005120	1	SPRING,RING	
13	5236018040	1	SWIVEL	
14	5196002010	1	VALVE AY,THROTTLE	
15	5206008030	2	SCREW COLLAR THROTTLE	
16	5236046010	4	SCREW,PUMP COVER	
17	5016004010	1	SCREEN,INLET	

HT490WV PARTS LIST

20	5253055010	1	COVER,AIR CLEANER	
21	5203004010	1	AIR FILTER	
22	5253003020	1	HOUSING AY AIR CLEANER	
23	0043305600	2	SCREW ASSY	
24	5236061000	1	O RING	
26	5256501900	1	BRACKET,CABLE	
29	5103502800	2	GASKET,AIR CLEANER	
		1		
31	5316020020	1	SCREW CABLE ADJ	
32	0022706000	1	NUT	M6
	5199505100	1	INSTRADTION MANUAL	

HT490WV PARTS LIST
